Phone sleeve in leather



The products you need:

- Leather
- Cutting board
- Punch tongs
- Ruler
- Rotary knife
- Needle
- Thread
- Space maker
- Pencil

Step 1 Use your phone to sketch out the right size on the leather. After this, make a small incision to make it easier getting your phone out of the cover. Step 2 Cut one of the sides following the outline with your rotary knife. Step 3 Fold the leather and use the side, you just cut, as a template for the other side, so that they become identical. After outlining, cut the side. Step 4 Use your space maker to mark, where the holes will be. Step 5 Use the rotary punch to punch holes in the leather. 92 08

Step 6	Sa # 111.
Don't make any holes in the fold of the leather.	
Step 7	8
Put needles in both ends of the thread.	
Step 8	
Start stitching from the bottom. Stick your needle through the bottom hole and make sure that the thread is of same length in each side.	
Step 9	
Stick the needles through the same hole to make the threads cross each other. Remember to tighten well.	
Step 10	
Tie a couple of knots on the inner side to finish off your stitch.	